




























































Original	Rechange	Original	Rechange
PWR On/Off	 Power	Menu	 Menu / Home
Mute	 Mute / Dimmer	Menu Up	 Up
H/V Play	 Play / Slow	Info	 Info / Angle
Dec/Pause	 Pause / Step / Freeze	Menu Left	 Left
East	 Rec / Rec Mode	OK Enter	 OK
Lang./Rewind	 << / Tune-	Menu Right	 Right
LNB F.Forward	 >> / Tune+	Exit	 Exit / Cancel / Clear
West	 << / Preset-	Menu Down	 Down
Dev	 >> / Preset+	Volume+	 Vol+
Lang./Rewind	 Sound / Title	TV/SAT	 Smart / List
Audio	 Audio / Lang I/II	CH/Page+	 CH+ / Page+
Subt.List	 Subtitle / EQ	Volume-	 Vol-
Zoom	 Zoom / Size	Display	 Display / Media
Sleep Timer	 Sleep / Timer	CH/Page-	 CH- / Page-
TV	 TV/Radio /	1. ?	 1
Opt?	 Setup / OPT /	2abc	 2
Text	 Text / Goto	3def	 3



Original	Recharge	Original	Recharge
4ghi	 4	TV/SAT	 +  Shift + 0
5jkl	 5	App	 +  Shift + Green / APP /
6mno	 6		
7pqrm	 7		
8tuv	 8		
9wxyz	 9		
Guide Pilote	 Guide / EPG / -/--		
0/10	 0		
FAV Pref.	 Fav / Marker / PC		
Red	 Red / Netflix / Search		
Green	 Green / APP / Repeat		
Yellow	 Yellow / YouTube / Repeat		
Blue	 Blue / Prime Video / Random		
Freeze	 +  Shift + Pause / Step /		
TV	 +  Shift + 1		
Video	 +  Shift + 4		
Epg	 +  Shift + Guide / EPG / -/--		

