






































| Original | Recharge |
|--|---|
|  Power |  Power |
|  HDD |  Shift + Media |
|  DVD |  Media |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/-- |  Guide |
|  Cancel |  Exit |
|  AV |  AV |
|  Input Select |  Eject |

| Original | Recharge |
|---|---|
|  Direct Tv Rec |  TV/R |
|  ShowView |  3D |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  I<< Skip |  I<< |
|  Skip >>I |  >>I |
|  << Slow/Search |  << |
|  Slow/Search >> |  >> |
|  Pause |  Pause |
|  Stop |  Stop |
|  Play |  Play |
|  Menu / Play List |  Menu |
|  Top Menu / Direct Navigator |  D. Menu |
|  Functions |  Options |
|  Return |  Back |









































| Original | Recharge |
|--|---|
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Enter |  Ok |
|  Rec |  Rec |
|  Frame II > |  Shift + Right |
|  < Frame |  Shift + Left |
|  Manual Skip |  Format |
|  Erase |  Text |
|  Time Slip |  Smart |
|  Prog/Check |  Sleep |
|  Timer |  Shift + AV |
|  Marker |  Pre Ch |
|  Dubbing |  Subt |
|  Status |  List |
|  Rec Mode |  Shift + Rec |

| Original | Recharge |
|--|--|
|  A/Display |  Red |
|  A/Display |  Info |
|  B/Position |  Green |
|  C/Audio |  Yellow |
|  C/Audio |  Dual |
|  D/AV Link |  Blue |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |





| | Original | Recharge |
|---|----------|--|
|  | Power |  Power |
|  | CH+ |  Ch + |
|  | CH- |  Ch - |
|  | 1 |  1 |
|  | 2 |  2 |
|  | 3 |  3 |
|  | 4 |  4 |
|  | 5 |  5 |
|  | 6 |  6 |
|  | 7 |  7 |
|  | 8 |  8 |
|  | 9 |  9 |
|  | 0 |  0 |
|  | -/-- |  Guide |
|  | A |  Red |
|  | B |  Green |
|  | C |  Yellow |

| | Original | Recharge |
|---|----------|--|
|  | D |  Blue |

