



| | Original | Rechange |
|--|----------|----------|
| | Power | Power |
| | Setup | Options |
| | Mute | Mute |
| | Function | Menu |
| | 1 | 1 |
| | 2 | 2 |
| | 3 | 3 |
| | 4 | 4 |
| | 5 | 5 |
| | 6 | 6 |
| | 7 | 7 |
| | 8 | 8 |
| | 9 | 9 |
| | 0 | 0 |
| | Audio | Dual |
| | Subtitle | Subt |
| | Digest | Smart |

| | Original | Rechange |
|--|---------------|----------|
| | EPG | Guide |
| | Info | Info |
| | FAV | Pre Ch |
| | Red/Photo | Red |
| | Green/Music | Green |
| | Yellow/Movie | Yellow |
| | Blue/Calendar | Blue |
| | Zoom | Eject |
| | Teletext | Text |
| | Tv/Radio | TV/R |
| | Recall | Back |
| | Exit | Exit |
| | Up | Up |
| | Down | Down |
| | Right | Right |
| | Left | Left |
| | Play/Pause | Ok |



