







































| Original | Rechange | Original | Rechange |
|---|------------|---|-----------------------------|
|  | Power |  | Power |
|  | Mute |  | Mute / Dimmer |
|  | V-Format |  | Picture / Format |
|  | Sleep |  | Sleep / Timer |
|  | FAV |  | Fav / Marker / PC |
|  | TV / Radio |  | TV/Radio / |
|  | List |  | Smart / List |
|  | SAT |  | Shift + 0 |
|  | Zoom |  | Zoom / Size |
|  | Subtitle |  | Subtitle / EQ |
|  | Vol + |  | Vol+ |
|  | Info |  | Info / Angle |
|  | CH+ |  | CH+ / Page+ |
|  | Vol - |  | Vol- |
|  | Recall |  | Back / Return |
|  | CH- |  | CH- / Page- |
|  | Menu |  | Menu / Home |
|  | Text |  | Text / Goto |
|  | Guide |  | Guide / EPG / -/- |
|  | Exit |  | Exit / Cancel / Clear |
|  | Up |  | Up |
|  | Page Down |  | Shift + CH- / |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Page Up |  | Shift + CH+ / |
|  | Down |  | Down |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |



