




Original	Rechange	Original	Rechange
 Power	 Power	 Exit	 Exit
 Input	 AV	 Vol+	 Vol +
 TV/TXT	 Text	 Vol-	 Vol -
 Cancel	 Eject	 Mute	 Mute
 Reveal	 Media	 Channel List	 TV/R
 Nicam/A2	 Dual	 EPG	 Guide
 Hold	 Options	 Info	 Info
 Size	 Format	 Up	 Up
 Subpage	 D. Menu	 Down	 Down
 Index	 Smart	 Right	 Right
 Red	 Red	 Left	 Left
 Green	 Green	 OK	 Ok
 Yellow	 Yellow	 1	 1
 Blue	 Blue	 2	 2
 CH+	 Ch +	 3	 3
 CH-	 Ch -	 4	 4
 Menu	 Menu	 5	 5



