




































































































Original		Rechange		Original		Rechange	
	Power		Power		Blue		Blue
	Source		AV		P.Mode		Shift + Format
	1		1		S.Mode		Shift + Dual
	2		2		Aspect		3D
	3		3		TXT		Text
	4		4		Audio		Dual
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right
	8		8		Left		Left
	9		9		Enter		Ok
	0		0		PR+		Ch +
	-/--		Shift + Guide		PR-		Ch -
	Recall		Back		Vol+		Vol +
	Red		Red		Vol-		Vol -
	Green		Green		Mute		Mute
	Yellow		Yellow		Display		Info





	Original	Recharge	Original	Recharge
	Sleep	 Sleep	 >>/PgDn	 >>
	Rec	 Rec	 <</PgUp	 <<
	Menu	 Menu	 Stop	 Stop
	Hold	 Options	 Play	 Play
	MIX	 Media	 Pause	 Pause
	Subpg.	 +  Shift + Subt	 Repeat	 +  Shift + Text
	Index	 Exit		
	Size	 Format		
	Reveal	 Smart		
	DTV/Radio	 TV/R		
	EPG	 Guide		
	FAV	 Pre Ch		
	List	 List		
	PVR Menu	 D. Menu		
	DTV Subt.	 Subt		
	I<<	 I<<		
	>>I	 >>I		

