







































































| Original | Rechange | Original | Rechange |
|----------|---|-----------------------|----------|
| Power |  | Power | |
| Recall |  | Back / Return | |
| CC |  | Subtitle / EQ | |
| Text |  | Text / Goto | |
| Smart |  | Smart / List | |
| Sleep |  | Sleep / Timer | |
| 1 |  | 1 | |
| 2 |  | 2 | |
| 3 |  | 3 | |
| 4 |  | 4 | |
| 5 |  | 5 | |
| 6 |  | 6 | |
| 7 |  | 7 | |
| 8 |  | 8 | |
| 9 |  | 9 | |
| 0 |  | 0 | |
| Reset |  | Exit / Cancel / Clear | |

| Original | Rechange | Original | Rechange |
|------------|---|-----------------------------------|----------|
| CH / Guide |  | Guide / EPG / -/-- | |
| Up |  | Up | |
| M |  | Menu / Home | |
| A / CH |  | Info / Angle | |
| Down |  | Down | |
| Vol+ |  | Vol+ | |
| Vol- |  | Vol- | |
| Left / - |  | Left | |
| Right / + |  | Right | |
| Mute |  | Mute / Dimmer | |
| CH+ |  | CH+ / Page+ | |
| CH- |  | CH- / Page- | |
| A |  | Red / Netflix / Search | |
| B |  | Green / APP / Repeat | |
| C |  | Yellow / YouTube / Repeat | |
| D |  | Blue / Prime Video / Random | |
| G |  | Shift + Yellow / YouTube / Repeat | |






































| Original | Rechange | Original | Rechange |
|----------|---|------------|---|
| Power |  Power | Up |  Up |
| Recall |  Back / Return | CH / Guide |  Guide / EPG / -/-- |
| CC |  Subtitle / EQ | Down |  Down |
| Text |  Text / Goto | M |  Menu / Home |
| Smart |  Smart / List | Vol+ |  Vol+ |
| Sleep |  Sleep / Timer | A / CH |  Info / Angle |
| 1 |  1 | Vol- |  Vol- |
| 2 |  2 | Mute |  Mute / Dimmer |
| 3 |  3 | Left / - |  Left |
| 4 |  4 | Right / + |  Right |
| 5 |  5 | CH+ |  CH+ / Page+ |
| 6 |  6 | CH- |  CH- / Page- |
| 7 |  7 | A |  Red / Netflix / Search |
| 8 |  8 | B |  Green / APP / Repeat |
| 9 |  9 | C |  Yellow / YouTube / Repeat |
| 0 |  0 | D |  Blue / Prime Video / Random |
| Reset |  Exit / Cancel / Clear | Clock |  Shift + Sleep / Timer |





| Original | Recharge | Original | Recharge |
|----------|---|-----------------------|----------|
| Power |  | Power | |
| Recall |  | Back / Return | |
| CC |  | Subtitle / EQ | |
| Text |  | Text / Goto | |
| Smart |  | Smart / List | |
| Sleep |  | Sleep / Timer | |
| 1 |  | 1 | |
| 2 |  | 2 | |
| 3 |  | 3 | |
| 4 |  | 4 | |
| 5 |  | 5 | |
| 6 |  | 6 | |
| 7 |  | 7 | |
| 8 |  | 8 | |
| 9 |  | 9 | |
| 0 |  | 0 | |
| Reset |  | Exit / Cancel / Clear | |

| Original | Recharge | Original | Recharge |
|------------|---|--------------------------------|----------|
| CH / Guide |  | Guide / EPG / -/-- | |
| Up |  | Up | |
| Down |  | Down | |
| A / CH |  | Info / Angle | |
| M |  | Menu / Home | |
| Right / + |  | Right | |
| Left / - |  | Left | |
| Vol+ |  | Vol+ | |
| Vol- |  | Vol- | |
| Mute |  | Mute / Dimmer | |
| CH+ |  | CH+ / Page+ | |
| CH- |  | CH- / Page- | |
| A |  | Red / Netflix / Search | |
| B |  | Green / APP / Repeat | |
| C |  | Yellow / YouTube / Repeat | |
| D |  | Blue / Prime Video / Random | |
| E |  | Shift + Red / Netflix / Search | |



