








































































Original		Rechange		Original		Rechange	
	Power		Power		1		1
	Pause/Slow		Pause		2		2
	Rec		Rec		3		3
	Index >>I		>>I		4		4
	I<< Index		I<<		5		5
	Search		TV/R		6		6
	Up		Up		7		7
	Play		Play		8		8
	Down		Down		9		9
	Stop		Stop		0		0
	Right		Right		-/--		Guide
	>>		>>		AV/Input Select	 + 	Shift + AV
	<<		<<		Tracking/V-Look+		Ch +
	Left		Left		Tracking/V-Look-		Ch -
	Menu		Menu		Vol+		Vol +
	Exit		Exit		Vol-		Vol -
	OK		Ok		Show View		Smart



