












| Original |              | Recharge |                          | Original |              | Recharge |                               |
|----------|--------------|----------|--------------------------|----------|--------------|----------|-------------------------------|
|          | Power        |          | Power                    |          | CH-          |          | CH- / Page-                   |
|          | TV Power     |          | Shift + Power            |          | 7            |          | 7                             |
|          | TV Vol+      |          | Shift + Vol+             |          | 8            |          | 8                             |
|          | TV Vol+      |          | Vol+                     |          | 9            |          | 9                             |
|          | TV CH+       |          | Shift + CH+ /            |          | ShowView     |          | Picture / Format              |
|          | Drive Select |          | Text / Goto              |          | */Delete     |          | Shift + Exit / Cancel / Clear |
|          | TV AV        |          | Shift + AV / Input / RDS |          | 0            |          | 0                             |
|          | TV Vol-      |          | Shift + Vol-             |          | Input Select |          | AV / Input / RDS              |
|          | TV Vol-      |          | Vol-                     |          | Status       |          | Info / Angle                  |
|          | TV CH-       |          | Shift + CH- /            |          | I<< Skip     |          | I<< / Preset-                 |
|          | 1            |          | 1                        |          | Skip >>I     |          | >>I / Preset+                 |
|          | 2            |          | 2                        |          | <<           |          | << / Tune-                    |
|          | 3            |          | 3                        |          | >>           |          | >> / Tune+                    |
|          | CH+          |          | CH+ / Page+              |          | Stop         |          | Stop / Hold                   |
|          | 4            |          | 4                        |          | Pause        |          | Pause / Step / Freeze         |
|          | 5            |          | 5                        |          | Play / 1.3   |          | Play / Slow                   |
|          | 6            |          | 6                        |          | Time Slip    |          | Sleep / Timer                 |





| Original  | Recharge  |
|---|---|
|  Prog / Check              |  TV/Radio /                    |
|  Exit                      |  Exit / Cancel / Clear         |
|  Direct Navigator          |  Smart / List                  |
|  Left / <                  |  Left                          |
|  Up                        |  Up                            |
|  Right /   >               |  Right                         |
|  Function Menu             |  Menu / Home                   |
|  OK                        |  OK                            |
|  Option                    |  Setup / OPT /                 |
|  Down                      |  Down                          |
|  Return                    |  Back / Return                 |
|  Red / Audio               |  Audio / Lang I/II             |
|  Red / Audio             |  Red / Netflix / Search      |
|  Green / Display         |  Display / Media             |
|  Green / Display         |  Green / APP / Repeat        |
|  Yellow / Create Chapter |  Yellow / YouTube / Repeat   |
|  Blue / Manual Skip      |  Blue / Prime Video / Random |

| Original  | Recharge   |
|---|--|
|  Rec           |  Rec / Rec Mode         |
|  Rec Mode      |  Shift + Rec / Rec Mode |
|  Ext Link      |  D.Menu / Top           |
|  Direct Tv Rec |  Eject / Surround       |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |

