























































Original	Recharge	Original	Recharge
	Power		Power
	Coax		Red
	Optical		Green
	Aux		Yellow
	Audio In		Blue
	Usb		Media
	Bluetooth		Smart
	Hdmi Arc		Options
	I<		I<<
	>I		>>I
	Play		Play
	Pause		Pause
	Bass+		Up
	Bass-		Down
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Treble+		Ch +
	Treble-		Ch -
	Sound		Dual
	Surround Off		Left
	Surround On		Right
	Audio Sync-		<<
	Audio Sync+		>>
	Dim		Guide
	Night		Pre Ch

