






















































	Original	Rechange		Original	Rechange
	Power		Power		Left
	Pause		Pause		Ch +
	Stop		Stop		Ch -
	Rec		Rec		Smart
	Play		Play		Back
	>>		>>		Source
	<<		<<		III/Adjust
	>		>>		Options
	<		<<		Find
	Red		Red		Mute
	Green		Green		Vol +
	Yellow		Yellow		Vol -
	Blue		Blue		1
	OK		Ok		2
	Up		Up		3
	Down		Down		4
	Right		Right		5



