














	Original	Recharge
	Power	 Power
	Vol-	 Vol -
	Vol+	 Vol +
	I< Title-	 I<<
	>I Title+	 >>I
	<< Album-	 <<
	>> Album+	 >>
	Rev / Program	 Options
	A-B / Display	 Info
	Timer ON/OFF	 AV
	Sleep	 Sleep
	DBB	 Smart
	DSC	 Media
	IS	 Format
	Mute	 Mute

Original	Recharge





	Original	Recharge	Original	Recharge
		Power		Power
		Vol-		Vol -
		Vol+		Vol +
		I< Title-		I<<
		>I Title+		>>I
		<< Album-		<<
		>> Album+		>>
		Stop		Stop
		Play		Play
		Pause		Pause
		Rev / Program		Options
		A-B / Display		Info
		Timer ON/OFF		AV
		Sleep		Sleep
		DBB		Smart
		DSC		Media
		IS		Format





Original	Recharge	Original	Recharge
 Power	 Power	 Mute	 Mute
 Vol-	 Vol -		
 Vol+	 Vol +		
 I< Title-	 I<<		
 >I Title+	 >>I		
 << Album -	 <<		
 >> Album+	 >>		
 Stop	 Stop		
 Play	 Play		
 Pause	 Pause		
 Rev / Program	 Options		
 A-B / Display	 Info		
 Timer ON/OFF	 AV		
 Sleep	 Sleep		
 DBB	 Smart		
 DSC	 Media		
 IS	 Format		





Original		Recharge	
	Power		Power
	Vol-		Vol -
	Vol+		Vol +
	Timer ON/OFF		AV
	Sleep		Sleep
	DBB		Smart
	DSC		Media
	IS		Format
	Mute		Mute

Original		Recharge	

