































Original	Rechange	Original	Rechange
	Power		Power
	Input		AV
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	OK		Ok
	Menu		Menu
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute
	P +		Ch +

Original	Rechange	Original	Rechange
	P -		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info
	P < P		Back
	[1 2]		Smart
	[[<<]]		Format
	[>>]		Stop



