







































































Original		Recharge		Original		Recharge	
	Power		Power		Down		Down
	Open / Close		Eject / Surround		Options		Setup / OPT /
	AUX / MP3 Link		Shift + 7		I<		I<< / Preset-
	Radio		Shift + 6		Play/pause		Play / Slow
	Radio		TV/Radio /		>I		>>I / Preset+
	USB		Shift + 8		Mute		Mute / Dimmer
	DOCK		Shift + 2		Stop		Stop / Hold
	Disc		Shift + 3		Vol+		Vol+
	Info		Info / Angle		Surround		Shift + Eject / Surround
	Up		Up		Sound Modes+		CH+ / Page+
	Left/Left		<< / Tune-		Vol-		Vol-
	Left/Left		Left		Sound Modes-		CH- / Page-
	OK		OK		1		1
	Right/Right		>> / Tune+		2		2
	Right/Right		Right		3		3
	Menu/Back		Back / Return		4		4
	Menu/Back		Menu / Home		5		5





Original		Recharge		Original		Recharge	
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ				
0	0	HDMI - BAT 0	0				
AUDIO SYNC	Audio/Sync	LANG I/II AUDIO	Audio / Lang I/II				
REPEAT PROGRAM	Repeat/Program	APP REPEAT	Green / APP / Repeat				
REPEAT PROGRAM	Repeat/Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program				
REPEAT A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
ZOOM	Zoom	SIZE ZOOM	Zoom / Size				
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer				

