



Original	Recharge
Standby/On	Power
DVD/CD	+  Shift + 3
DVD/CD	+  Shift + 2
Tuner/FM/AM	+  Shift + 6
TV	+  Shift + 1
Line/L1/L2	+  Shift + 4
Display	Display / Media
Pause	Pause / Step / Freeze
Open/Close	Eject / Surround
<</<I/<I	<< / Tune-
Play	Play / Slow
II>/I>/>>	>> / Tune+
I<<	I<< / Preset-
Stop	Stop / Hold
>>I	>>I / Preset+
DVD Menu	D.Menu / Top
Up/Tune+	+  Shift + >> / Tune+



































Tune+

Original	Recharge
Up/Tune+	Up
Return	Back / Return
Left/ST-	Left
Enter	OK
Right/ST+	Right
Mute	Mute / Dimmer
Down/Tune-	+  Shift + << /
Down/Tune-	Down
Sound	Sound / Title
Volume	Vol+
Volume Master-	Vol-
CH+ Tv Control	+  Shift + CH+ /
Power Tv Control	+  Shift + Power
Vol+ Tv Control	+  Shift + Vol+
CH- Tv Control	+  Shift + CH- /
Input Tv Control	+  Shift + AV / Input / RDS
Vol- Tv Control	+  Shift + Vol-





Original	Rechange
 Auto	 Smart / List
 Bass Mode	 Shift + EQ Subtitle / EQ
 Dialogue	 Shift + Audio / Lang I/II
 Surround	 Shift + Eject / Surround
 Virtual SB	 AV / Input / RDS
 Advanced	 Picture / Format
 Program	 TV/Radio /
 Audio	 Audio / Lang I/II
 Repeat	 Green / APP / Repeat
 Subtitle	 Subtitle / EQ
 Random	 Blue / Prime Video / Random
 Angle	 Info / Angle
 1	 1
 Zoom	 Zoom / Size
 2	 2
 Top Menu	 Shift + D.Menu / Top Menu
 3	 3

Original	Rechange
 Home Menu	 Menu / Home
 4	 4
 System Setup	 Setup / OPT /
 5	 5
 Test Tone	 Text / Goto
 6	 6
 CH Level	 Shift + Smart / List
 7	 7
 Dimmer	 Shift + Mute / Dimmer
 8	 8
 Quiet/Midnight	 Shift + Sleep / Timer
 9	 9
 Timer/Clock	 Sleep / Timer
 CLR	 Exit / Cancel / Clear
 0	 0
 Folder-	 CH- / Page-
 Folder+	 CH+ / Page+





Original

Recharge

	Room Setup		+		Shift + Setup / OPT / Tools

Original

Recharge