





















	Original	Recharge	Original	Recharge
	Power			
	Dimmer			
	CD			
	Phono			
	Tape			
	Tuner			
	AUX			
	Mute			
	Vol+			
	Vol-			
	Tone/BAL			
	L/-			
	R/+			
	Direct			

