



































































Original		Recharge		Original		Recharge	
	Power		Power		Yellow		Yellow
	Play		Play		Blue		Blue
	Pause		Pause		CH+		Ch +
	<<		<<		CH-		Ch -
	>>		>>		Source		AV
	l<<		l<<		Vol+		Vol +
	>>l		>>l		Vol-		Vol -
	Stop		Stop		Menu		Menu
	TV/TXT		Text		Rec		Rec
	Cancel		Eject		Up		Up
	Reveal		D. Menu		Down		Down
	Hold		Media		Right		Right
	Size		3D		Left		Left
	Subpage		Shift + Subt		OK		Ok
	Index		List		DVB		Smart
	Red		Red		Exit		Exit
	Green		Green		1		1





Original	Rechange	Original	Rechange
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
-/--	-/--	SHIFT + -/--	Shift + Guide
RECALL	Recall	RETURN	Back
PICTURE	Picture	SHIFT + PICTURE	Shift + Format
SOUND	Sound	SHIFT + SOUND	Shift + Dual
NICAM/A2	Nicam/A2	SETTINGS	Options
MUTE	Mute	MUTE	Mute
SLEEP	Sleep	PROG	Sleep
TV/RADIO	Tv/Radio	SEARCH	TV/R
FAV	FAV	FAV	Pre Ch
FAV+	FAV+	SHIFT + +	Shift + Ch +
FAV-	FAV-	SHIFT + -	Shift + Ch -
SUBTITLE	Subtitle	AD	Subt
PIC FORMAT	Pic Format	PICTURE	Format
TEXT	Text	SHIFT + REPEAT	Shift + Text
DISPLAY	Display	DISPLAY	Info
LANGUAGE	Language	SOUND	Dual
EPG	EPG	-/--	Guide

