










































Original	Rechange	Original	Rechange
 POWER	 Power	 8	 8
 MUTE	 Mute / Dimmer	 9	 9
 P. MODE	 Picture / Format	 -/--	 Shift + Guide / EPG / -/--
 S. MODE	 Sound / Title	 0	 0
 TV / RADIO	 TV/Radio /	 BACK	 Back / Return
 NICAM	 Shift + Audio / Lang I/II	 REC. MENU	 D.Menu / Top
 DISPLAY	 Display / Media	 PLAY / PAUSE	 Play / Slow
 ZOOM / PC.A	 Shift + Zoom /	 SKIP PREV	 I<< / Preset-
 SLEEP	 Sleep / Timer	 SKIP NEXT	 >>I / Preset+
 EDIT	 Shift + Text /	 REC	 Rec / Rec Mode
 1	 1	 STOP	 Stop / Hold
 2	 2	 REW	 << / Tune-
 3	 3	 FWD	 >> / Tune+
 4	 4	 CH+	 CH+ / Page+
 5	 5	 SOURCE	 AV / Input / RDS
 6	 6	 VOL+	 Vol+
 7	 7	 CH-	 CH- / Page-





Original		Recharge		Original		Recharge	
	VOL-		Vol-		UPDATE / A-B		Shift + Yellow / YouTube /
	MENU		Menu / Home		SUBPAGE /		Audio / Lang I/II
	EXIT		Exit / Cancel / Clear		HOLD / FRE. / SUB. T.		Shift + Stop /
	UP		Up		RED / INFO		Shift + Info / Angle
	LEFT		Left		RED / INFO		Red / Netflix / Search
	OK		OK		Green / Angle		Info / Angle
	RIGHT		Right		Green / Angle		Green / APP / Repeat
	DOWN		Down		YELLOW / SLOW		Yellow / YouTube / Repeat
	FAV		Fav / Marker / PC		BLUE / EJECT		Blue / Prime Video / Random
	EPG		Guide / EPG / -/--		EJECT		Eject / Surround
	USB		Shift + 8				
	SETUP / ON/OFF		Setup / OPT /				
	MIX / MENU		Smart / List				
	INDEX / PCB		Text / Goto				
	ZOOM / SIZE		Zoom / Size				
	REVEAL / SUBT. / REP.		Shift + Green / APP /				
	SUB. T.		Subtitle / EQ				

