










































































Original		Recharge		Original		Recharge	
	Power		Power		Left		Left
	Mute		Mute		OK		Ok
	1		1		Right		Right
	2		2		Down		Down
	3		3		Red		Red
	4		4		Green		Green
	5		5		Yellow		Yellow
	6		6		Blue		Blue
	7		7		Vol +		Vol +
	8		8		Vol -		Vol -
	9		9		EPG		Guide
	0		0		00:00		AV
	[≡]		Text		CH +		Ch +
	←		Back		CH -		Ch -
	Menu		Menu		[<<]		3D
	Exit		Exit		[_]		Subt
	Up		Up		Lang		Dual





Original	Rechange	Original	Rechange
	□ / ♪	SEARCH TV/R	TV/R
	♥	FAV PRE-CH	Pre Ch
	(i)	DISPLAY INFO	Info

