


















































| Original | Recharge | Original | Recharge |
|--------------|--|------------|---|
| On/Off |  Power | Zoom |  +  Shift + Eject |
| Audio Off |  Mute | Menu Up |  Up |
| Slow Down |  Ch - | Display |  Info |
| Subt. |  Subt | Menu Left |  Left |
| Auto/Track |  3D | OK Enter |  Ok |
| Title |  List | Menu Right |  Right |
| Slow Up |  Ch + | Menu Down |  Down |
| Rep/A-B |  +  Shift + Text | Volume+ |  Vol + |
| Menu |  Menu | Prev. |  I<< |
| Stop |  Stop | Volume- |  Vol - |
| DVD/TV |  TV/R | 1 |  1 |
| Pause |  Pause | 2 |  2 |
| Pepeat/1/All |  Text | 3 |  3 |
| Progr. |  Sleep | 4 |  4 |
| Next |  >>I | 5 |  5 |
| Return |  Back | 6 |  6 |
| Top Menu |  D. Menu | 7 |  7 |



| Original | Recharge | Original | Recharge |
|--------------|---|----------|----------|
| 8 |  | 8 | |
| 9 |  | 9 | |
| +10 |  | Guide | |
| Record |  | Rec | |
| 0 |  | 0 | |
| Play |  | Play | |
| Rewind |  | << | |
| C/CH |  | Pre Ch | |
| F.Forward |  | >> | |
| Mark |  +  Shift + 7 | | |
| Open/Close |  | Eject | |
| Input Source |  | AV | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

