




















































































| Original | | Rechange | | Original | | Rechange | |
|---|----------|---|---------------|---|----------|---|----------------|
|  | Standby |  | Power |  | Vol- |  | Vol - |
|  | Auto |  | Smart |  | CH+ |  | Ch + |
|  | Tv/Radio |  | TV/R |  | CH- |  | Ch - |
|  | Mute |  | Mute |  | Nicam/A2 |  | Options |
|  | 1 |  | 1 |  | Aspect |  | 3D |
|  | 2 |  | 2 |  | Display |  | Info |
|  | 3 |  | 3 |  | Up |  | Up |
|  | 4 |  | 4 |  | Down |  | Down |
|  | 5 |  | 5 |  | Right |  | Right |
|  | 6 |  | 6 |  | Left |  | Left |
|  | 7 |  | 7 |  | OK |  | Ok |
|  | 8 |  | 8 |  | Menu |  | Menu |
|  | 9 |  | 9 |  | Exit |  | Exit |
|  | 0 |  | 0 |  | Source |  | AV |
|  | -/-- |  | Shift + Guide |  | P.Mode |  | Shift + Format |
|  | Back |  | Back |  | S.Mode |  | Shift + Dual |
|  | Vol+ |  | Vol + |  | Sleep |  | Sleep |





| Original | Rechange |
|---|--|
|  Fav |  Pre Ch |
|  Fav- |  Shift + Ch - |
|  Fav+ |  Shift + Ch + |
|  Hold |  Shift + AV |
|  EPG |  Guide |
|  Text |  Text |
|  Lang |  Dual |
|  Subtitle |  Subt |
|  Index |  List |
|  Reveal |  Eject |
|  Subpage |  D. Menu |
|  Media |  Media |
|  Size |  Format |
|  Play |  Play |
|  Pause |  Pause |
|  << |  << |
|  >> |  >> |

| Original | Rechange |
|--|--|
|  Rec |  Rec |
|  Stop |  Stop |
|  I<< |  I<< |
|  >>I |  >>I |
|  Red |  Red |
|  Green |  Green |
|  Yellow |  Yellow |
|  Blue |  Blue |

