




















































Original	Recharge
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 [≡?]/Source	 AV
 [≡i]/Info	 Info
 DMP	 Smart
 EPG	 Guide
 Menu	 Menu

Original	Recharge
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 List	 List
 CH+	 Ch +
 CH-	 Ch -
 ♥	 Pre Ch
 Sleep	 Sleep
 Index	 Media
 Back	 Back
 Red	 Red
 Green	 Green





Original		Rechange		Original	Rechange
	Yellow		Yellow		
	Blue		Blue		
	<<		<<		
	>>		>>		
	I<<		I<<		
	>>I		>>I		
	Play		Play		
	Pause		Pause		
	Stop/Still		Stop		
	[≡+]		Format		
	[≡]		Text		
	[≡o]/Subtitle		Subt		
	[≡◆]/[+]		3D		
	[≡x]		Options		
	Radio		TV/R		
	Audio		Dual		
	Rec		Rec		

