




















































Original	Recharge
 Red/Sound	 Sound / Title
 Red/Sound	 Red / Netflix / Search
 Green/Picture	 Picture / Format
 Green/Picture	 Green / APP / Repeat
 Yellow/P.	 Yellow / YouTube / Repeat
 Blue/VT	 Blue / Prime Video / Random
 Ino	 Smart / List
 TV	 TV/Radio /
 Zoom-/Stop	 Down
 Zoom+/Func VI	 Up
 -	 Vol-
 +	 Vol+
 Prog.-	 CH- / Page-
 Prog.+	 CH+ / Page+
 1	 1
 2	 2
 3	 3

Original	Recharge
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Mute	 Mute / Dimmer
 0/AV	 0
 0/AV	 AV / Input / RDS
 Power	 Power

