



Original	Recharge
Standby	Power
Off	Shift + Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
_/---/Del	GUIDE Guide
Mute	Mute
Vol+	Vol +
Vol-	Vol -
Content (Home)	HOME SMART Smart

Original	Recharge
Source	AV AV
CH+	Ch +
CH-	Ch -
MagicInfo/Lite /S	APP MEDIA Media
Menu	TOP MENU MENU Menu
Blank	FAV PRE-CH Pre Ch
Tools	SETTINGS OPT Options
Info	DISPLAY INFO Info
Return	RETURN BACK Back
Exit	CLEAR EXIT Exit
Up	Up
Down	Down
Right	Right
Left	Left
Enter	OK Ok
Red/PC	Red
Green/DVI	B Green



