







































































Original	Recharge	Original	Recharge
 Power	 Power	 CH List	 List
 Source	 AV	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Menu	 Menu
 3	 3	 Smart Hub	 Smart
 4	 4	 Guide	 Guide
 5	 5	 Tools	 Options
 6	 6	 Info	 Info
 7	 7	 Return	 Back
 8	 8	 Exit	 Exit
 9	 9	 Up	 Up
 0	 0	 Down	 Down
 TTX/MIX	 Text	 Right	 Right
 PRE-CH	 Pre Ch	 Left	 Left
 Vol+	 Vol +	 Enter	 Ok
 Vol-	 Vol -	 Red	 Red
 Mute	 Mute	 Green	 Green





Original		Recharge		Original		Recharge	
	Yellow		Yellow				
	Blue		Blue				
	Search		TV/R				
	Status		Media				
	AD/Subt.		Subt				
	E-Manual		D. Menu				
	Recommend		Format				
	3D		3D				
	<<		<<				
	I<<		I<<				
	Pause		Pause				
	>>		>>				
	>>I		>>I				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

