























































































































Original	Rechange	Original	Rechange
 Power	 Power	 >>	 >>
 Input	 AV	 V.Menu	 D. Menu
 1	 1	 Mute	 Mute
 2	 2	 P+	 Ch +
 3	 3	 P+	 Up
 4	 4	 P-	 Ch -
 5	 5	 P-	 Down
 6	 6	 Vol+	 Right
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Left
 9	 9	 Vol-	 Vol -
 0	 0	 Menu	 Menu
 -/-	 GUIDE	 Display	 Info
 Pre CH	 Pre Ch	 P.STD	 3D
 <<	 <<	 Rec	 Rec
 Stop	 Stop	 Eject	 Eject
 Play	 Play	 Pause / P/S	 Pause

Original	Rechange	Original	Rechange
 MUTE	 SHIFT	 TV	 AUX
 TV	 DVD	 SAT	 REC MODE
 DUAL	 SUBT	 OPT	 ECO
 REPEAT	 ZOOM	 TIMER	 AV
 MENU	 INFO	 OK	 BACK
 HOME	 SMART	 APP	 MEDIA
 CH +	 CH -	 1	 2
 1	 2	 3	 3
 2	 3	 4	 4
 3	 4	 5	 5
 4	 5	 6	 6
 5	 6	 7	 7
6	7	8	8
7	8	9	9
8	9	0	0
9	0	A	B
0	A	C	D
A	B	C	D



