



Original	Recharge
Power	Power
Function	Smart / List
1 / CD	1
1 / CD	Shift + 3
2 / VCR	2
2 / VCR	Shift + 4
3 / DVD	3
3 / DVD	Shift + 2
4 / 5.1 CH	4
5 / SAT	5
5 / SAT	Shift + 0
6 / AUX	6
6 / AUX	Shift + 7
7	7
8	8
9	9
Sleep	Sleep / Timer

Original	Recharge
0	0
Input Mode	AV / Input / RDS
EX/ES	Zoom / Size
Sub Woofer	Eject / Surround
TUNER	TV/Radio /
TUNER	Shift + 6
Mo. / St.	Sound / Title
Volume+	Vol+
Mute	Mute / Dimmer
Volume-	Vol-
Setup / Menu	Menu / Home
Setup / Menu	Setup / OPT /
Tuning Mode	Guide / EPG / -/--
Up	Up
Left	Left
Enter	OK
Right	Right



