



































	Original	Recharge	Original	Recharge
	Power			
	Start			
	Stop			
	Recharging			
	Max			
	Up			
	Left			
	Star/Stop			
	Right			
	Auto			
	Spot			
	Manual A1			
	Manual A2			
	Manual A3			
	Manual B1			
	Manual B2			
	Manual B3	