




























































































































































































































Original	Recharge	Original	Recharge
 Power	 Power	 -/--/[≡0]	 Guide
 Wide	 PICTURE FORMAT	 CS	 FAV PRE-CH
 Mute	 MUTE	 SURROUND	 A
 Tv/Source	 SEARCH TV/R	 Green	 B
 ▼ A-B	 SOUND DUAL	 BASS	 C
 →←	 HOME SMART	 Blue/Timer	 D
 [.] [Y] [≡?]	 APP MEDIA	 MENU	 TOP MENU MENU
 1	 1	 P↔P	 RETURN BACK
 2	 2	 P▲	 ▲
 3	 3	 P▲	 + CH
 4	 4	 P▼	 - CH
 5	 5	 P▼	 ▼
 6	 6	 ▶	 ▶
 7	 7	 ▶	 + VOL
 8	 8	 ◀	 ◀
 9	 9	 F/OK	 OK
 0	 0	 O/[≡x]	 AD SUBT

Original	Recharge	Original	Recharge
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 FF	 FF	 ■	 ■
		 ●	 ●
 RR	 RR	 SOUND	 SOUND
 ◀	 ◀	 AD	 AD
 FF	 FF	 SETTINGS	 SETTINGS
 LIST	 LIST	 OPT	 OPT
 PROG	 PROG	 ECO	 ECO
 SLEEP	 SLEEP	 3D	 3D
 E-MANUAL	 E-MANUAL	 TIMER	 TIMER
 D.MENU	 D.MENU	 AV	 AV
 TOP MENU	 TOP MENU	 DISPLAY INFO	 DISPLAY INFO
 MENU	 MENU	 OK	 OK
 RETURN	 RETURN	 BACK	 BACK
 EXIT	 EXIT	 CLEAR	 CLEAR
 HOME	 HOME	 SMART	 SMART
 APP	 APP	 MEDIA	 MEDIA
 + VOL	 + VOL	 + CH	 + CH
 - VOL	 - VOL	 - CH	 - CH
 1	 1	 2	 2
 2	 2	 3	 3
 3	 3	 4	 4
 4	 4	 5	 5
 5	 5	 6	 6
 6	 6	 7	 7
 7	 7	 8	 8
 8	 8	 9	 9
 9	 9	 FF	 FF
 0	 0	 FAV	 FAV
 GUIDE	 GUIDE	 PRE-CH	 PRE-CH
 A	 A	 B	 B
 B	 B	 C	 C
 C	 C	 D	 D
 D	 D	 Mandis SHOP	 Mandis SHOP
 Mandis SHOP	 Mandis SHOP	 www.mandis.tv	 www.mandis.tv





Original		Recharge		Original		Recharge	
	Power		Power				
	Menu		Menu				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	Enter		Ok				
	Pause		Pause				
	Next		>>				
	Play		Play				
	Prev		<<				
	Stop		Stop				

