








































































Original		Rechange		Original		Rechange	
	Power		Power		PIP/[]		3D
	Mute		Mute		Text/Disc M		Text
	Source		AV		Menu		Menu
	*/Zoom		Eject		Back/End		Back
	DR+/Pop-Up M.		D. Menu		Info		Info
	1		1		OK		Ok
	2		2		Up		Up
	3		3		Down		Down
	4		4		Right		Right
	5		5		Left		Left
	6		6		Vol+		Vol +
	7		7		Vol-		Vol -
	8		8		P+		Ch +
	9		9		P-		Ch -
	0		0		Red		Red
	EPG		Guide		Green		Green
	Home		Smart		Yellow		Yellow









































































Original		Recharge		Original		Recharge	
	Blue/Marker		Blue				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	<<		<<				
	>>		>>				





Original	Rechange	Original	Rechange
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Text/Disc M		Text
	EPG		Guide
	Home		Smart
	PIP/[]		3D
	Menu		Menu
	Back/End		Back
	Info		Info
	DR+/Pop-Up M		D. Menu
	*/Zoom		Eject
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue/Marker		Blue











Original		Recharge		Original		Recharge	
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	>>		>>				
	<<		<<				


















Original	Rechange
 Power	 Power
 Mute	 Mute
 DR+/Pop-Up M	 D. Menu
 */Zoom	 Eject
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 EPG	 Guide
 Home	 Smart

Original	Rechange
 PIP/[]	 3D
 Text/Disc M	 Text
 Menu	 Menu
 Back/End	 Back
 Info	 Info
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +
 P-	 Ch -
 Red	 Red
 Green	 Green
 Yellow	 Yellow



















































Original	Recharge	Original	Recharge
 Blue/Marker	 Blue		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Rec	 Rec		
 <<<	 <<<		
 >>>	 >>>		





Original	Rechange
 Power	 Power
 Mute	 Mute
 Up	 Up
 OK	 Ok
 Down	 Down
 Right	 Right
 Left	 Left
 */Zoom	 Format
 DR+/Pop-Up M	 Media
 0	 0
 Pip/[]	 3D
 Menu	 Menu
 Back/End	 Back
 Info	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 P+	 Ch +

Original	Rechange
 P-	 Ch -
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 >>	 >>
 <<	 <<

