





























Original		Rechange		Original		Rechange	
	Power		Power		Nicam/A2		Dual
	Auto		Options		System		Smart
	Mute		Mute		CH+		Ch +
	1		1		CH-		Ch -
	2		2		Display		Info
	3		3		Up		Up
	4		4		Left		Left
	5		5		Enter		Ok
	6		6		Right		Right
	7		7		Down		Down
	8		8		Exit		Exit
	9		9		Menu		Menu
	0		0		Input		AV
	-/--		Guide		PMode		Format
	Recall		Back		SMode		Shift + Dual
	Vol+		Vol +		Sleep		Sleep
	Vol-		Vol -		Text		Text





Original		Recharge		Original		Recharge	
	Hold		Stop				
	PgDn		I<<				
	PgUp		>>I				
	Index		List				
	Size		Eject				
	Reveal		Media				
	Subpage		Subt				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Cyan		Blue				

