




















































Original	Rechange
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Source	 AV
 Last View	 Pre Ch
 AV Mode	 Shift + AV
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -

Original	Rechange
 P+	 Ch +
 P-	 Ch -
 Menu	 Menu
 EPG	 Guide
 [≡]	 Text
 End	 Exit
 Back	 Back
 Home	 Smart
 3D	 3D
 Netflix	 Media
 ▼/O)/I/II/I+II	 Dual
 [<>]	 Format
 APP	 Shift + Media
 Eco	 Shift + 3D
 [...]	 Subt
 [≡?]	 Options
 [≡o]	 List





Original	Recharge
 [=+]	 Sleep
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Radio	 TV/R
 SAT	 Eject
 DTV	 Shift + Pre Ch
 ATV	 Shift + Guide
 P.Info	 Shift + Info
 [i+]	 Info
 Control	 D. Menu

Original	Recharge
 Power Ext	 Shift + Power
 Rec	 Rec
 Play	 Play
 <<	 <<
 >>	 >>
 Stop	 Stop
 <<	 <<
 >>	 >>
 Pause	 Pause
 Rec Stop	 Shift + Stop
 ←	 Shift + Left
 →	 Shift + Right

