







































































Original	Recharge	Original	Recharge
	Power		Power
	[≡]		Text
	INST		Smart
	Up / P+		Up
	Up / P+		Ch +
	Down / P-		Down
	Down / P-		Ch -
	Right / V+		Right
	Right / V+		Vol +
	Left / V-		Left
	Left / V-		Vol -
	Menu		Menu
	Menu		Ok
	[≡i]		Info
	□		Stop
	X		Exit
	↕ [+]		Options
			Subt
	?P<P		Back
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Mute		Mute



