





































Original	Recharge
 Standby	 Power
 Power Tv	 Shift + Power
 Speakers	 TV/R
 Eject	 Eject
 Visualizer	 Guide
 Dimmer	 Pre Ch
 Clear Audio+	 1
 Sound Field	 2
 Music EQ	 3
 Game	 4
 Night	 5
 Concert Hall	 6
 Football	 7
 Cinema Studio	 8
 Music Arena	 9
 Red	 Red
 Green	 Green

Original	Recharge
 Yellow	 Yellow
 Blue	 Blue
 Top Menu	 Menu
 Pop Up Menu	 D. Menu
 Return	 Back
 Options	 Options
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Mirroring	 Format
 Home	 Smart
 Bluetooth	 Exit
 SEN	 Text
 Display	 Info
 Function	 Media





	Original	Recharge	Original	Recharge
	Sleep	 Sleep		
	Audio	 Dual		
	Subtitle	 Subt		
	3D	 3D		
	<</Tuning-	 <<		
	I<</Preset-	 I<<		
	Play	 Play		
	Pause	 Pause		
	Stop	 Stop		
	>>/Tuning+	 >>		
	>>I/Preset+	 >>I		
	Vol+	 Vol +		
	Vol-	 Vol -		
	Mute	 Mute		
	Tv Vol+	 Shift + Vol +		
	Tv Vol-	 Shift + Vol -		
	Input Tv	 AV		

