







































































Original		Rechange		Original		Rechange	
	Power Tv		Power		Recall		Pre Ch
	Mute		Mute		Red/♪		Red
	I=Q		Dual		Green/*		Green
	[><]		3D		Yellow		Yellow
	Timer		Shift + AV		Blue/[+]		Blue
	Input/[+]		AV		[]		Format
	1		1		[≡]		Text
	2		2		Menu		Menu
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Pause		Pause
	9		9		Stop		Stop
	0		0		>>		>>
	[i+]/[?]		Info		<<		<<



