














































































Original		Rechange		Original		Rechange	
	Power		Power		5		5
	⏮		3D		6		6
	←		Back		7		7
	SAT		Smart		8		8
	Mute		Mute		9		9
	□		TV/R		0		0
	[=]		Text		-/--		Guide
	→ □ / [□]		AV		C		Exit
	□ → / [?]		Shift + AV		[=+]		Shift + Stop
	PIP / Split		Options		↑		Up
	PIP to Main		List		Vol+		Vol +
	PIP Swap / Split Swap		Pre Ch		Vol-		Vol -
	Split Hold		Shift + Pause		Prog+		Ch +
	1		1		Prog-		Ch -
	2		2		Red		Red
	3		3		Green		Green
	4		4		Yellow		Yellow























Original		Rechange		Original		Rechange	
	Blue		Blue		Stop		Stop
	[≡?][+]		Info		Pause		Pause
	↔◇		D. Menu				
	[⊙]		Sleep				
	■		Shift + Format				
	Aspect		Format				
	♪		Dual				
	+		Right				
	-		Left				
	Menu		Menu				
	OK		Ok				
	Power Down		Shift + Power				
	Prog+ Down		Shift + Ch +				
	Prog- Down		Shift + Ch -				
	<<		<<				
	Play		Play				
	>>		>>				























Original		Recharge		Original		Recharge	
	Power Down		Power				
	Prog+ Down		Ch +				
	Prog- Down		Ch -				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	>>		>>				
	Play		Play				
	<<		<<				























Original	Recharge	Original	Recharge
 Power Down	 Power		
 Prog+ Down	 Ch +		
 Prog- Down	 Ch -		
 Stop	 Stop		
 Pause	 Pause		
 Rec	 Rec		
 >>	 >>		
 Play	 Play		
 <<	 <<		





Original		Recharge		Original		Recharge	
	Power Down		Power				
	Prog+ Down		Ch +				
	Prog- Down		Ch -				
	<<		<<				
	Play		Play				
	>>		>>				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				

