



Original	Recharge	Original	Recharge
Eject/Thrater	Fav / Marker / PC	0	0
Input Tv	AV / Input / RDS	Subtitle	Subtitle / EQ
Power Tv	Shift + Power	Angle	Info / Angle
Power	Power	Red	Red / Netflix / Search
1	1	Green	Green / APP / Repeat
2	2	Yellow	Yellow / YouTube / Repeat
3	3	Blue	Blue / Prime Video / Random
Vol+	Vol+	Top Menu	D.Menu / Top
4	4	Up	Up
5	5	Pop Up Menu	Menu / Home
6	6	Left	Left
Vol-	Vol-	OK	OK
7	7	Right	Right
8	8	Return	Back / Return
9	9	Down	Down
Timer	Sleep / Timer	Option	Setup / OPT /
Audio	Audio / Lang I/II	Home/Player	Shift + Display / Media



