



Original	Recharge
 Sleep	 Sleep / Timer
 Power	 Power
 Mute	 Mute / Dimmer
 TV Format	 Setup / OPT /
 DVB	 Smart / List
 TV / AV	 AV / Input / RDS
 Info	 Info / Angle
 DVB Info	 Shift + Info / Angle
 Language	 Shift + Audio / Lang I/II
 Text	 Text / Goto
 Fav	 Fav / Marker / PC
 EPG	 Guide / EPG / -/--
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Audio	 Audio / Lang I/II
 Yellow	 Yellow / YouTube / Repeat
 Freeze	 Pause / Step / Freeze

Original	Recharge
 Blue	 Blue / Prime Video / Random
 DVB Menu	 D.Menu / Top
 DVB Exit	 Shift + Exit / Cancel / Clear
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 TV Menu	 Menu / Home
 Down	 Down
 TV Exit	 Exit / Cancel / Clear
 Vol+	 Vol+
 Display	 Display / Media
 P+	 CH+ / Page+
 Vol-	 Vol-
 Nicam	 Sound / Title
 P-	 CH- / Page-
 TV/Txt	 Shift + Text / Goto





5 5

