



Original		Recharge		Original		Recharge	
	Power		Power		Up		Up
	1		1		Down		Down
	2		2		Right/Zoom+		Right
	3		3		Left/Zoom-		Left
	4		4		OK		Ok
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Mute		Mute
	8		8		Smart Tv		Smart
	9		9		You Tube		Media
	0		0		CH+		Ch +
	Source		AV		CH-		Ch -
	Guide		Guide		Text		Text
	Menu		Menu		Subtitle		Subt
	Exit		Exit		List		List
	Option		Options		Info		Info
	Return		Back		O)/Lang		Dual



