



Original	Rechange
 Standby / On	 Power
 Dimmer	 Smart
 Sleep	 Sleep
 Timer	 AV
 Info / RDS	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Clear	 Exit
 Program	 Shift + Sleep

Original	Rechange
 FM Mode	 Media
 <<	 <<
 >>	 >>
 Repeat 1 / All	 Text
 Shuffle	 TV/R
 Stop	 Stop
 Play / Pause	 Play
 Play / Pause	 Pause
 Display	 Shift + Info
 Menu	 Menu
 Time Mode	 3D
 Up	 Up
 Left / I<<	 Left
 Left / I<<	 I<<
 Enter	 Ok
 Right / >>I	 Right
 Right / >>I	 >>I





Original		Rechange		Original	Rechange
	Down		Down		
	Tone / Bal		Dual		
	Muting		Mute		
	AUX 1		Shift + 1		
	AUX 2		Shift + 2		
	TUNER		Shift + 3		
	CD		Shift + 4		
	USB		Shift + 5		
	SD		Shift + 6		
	iPod		Shift + 7		
	Volume+		Vol +		
	Volume-		Vol -		

