







































































Original		Recharge		Original		Recharge	
	Standby		Power		Source / AV		AV
	TV / Radio		TV/R		Info		Info
	TV Guide		Guide		Up		Up
	Mute		Mute		Right		Right
	ATV		Shift + Smart		Down		Down
	USB		Media		Left		Left
	DVD		Smart		OK		Ok
	Eject		Eject		Menu		Menu
	Rec		Rec		Exit		Exit
	Rec List		Shift + Rec		1		1
	I<<		I<<		2		2
	>>I		>>I		3		3
	Stop		Stop		4		4
	<<		<<		5		5
	>>		>>		6		6
	Play / Pause		Play		7		7
	Play / Pause		Pause		8		8





	Original	Rechange
	9	9
	0	0
	Recall	Back
	Fav	Pre Ch
	Vol +	Vol +
	Vol -	Vol -
	Subtitle	Subt
	Aspect	Format
	Audio	Dual
	Sleep	Sleep
	CH +	Ch +
	CH -	Ch -
	Red / Goto	Red
	Green / A-B	Green
	Yellow / Angle	Yellow
	Blue / Repeat	Blue
	Blue / Repeat	Shift + Text

	Original	Rechange
	D.Dis	Shift + Info
	Zoom	Shift + Eject
	Size	3D
	Display (Power)	Shift + Power
	Text / D.Setup	Text
	Text / D.Setup	Options
	Index / D.Menu	D. Menu
	Reveal / Title	List
	Hold	Shift + Pause

