



































































































Original	Rechange
 Power	 Power
 Mute	 Mute
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/AV	 0
 Rec	 Rec
 Tv/Radio	 TV/R
 <<<	 <<<
 Stop/DVR	 Stop

Original	Rechange
 Play/Pause	 Play
 >>>	 >>>
 SFI	 Guide
 www	 Media
 ↑	 >>>
 ↓	 <<<
 Recall/Zurück	 Back
 Info/Vor	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 P+	 Ch +
 P-	 Ch -
 OPT	 Options
 NAV	 List





Original		Rechange		Original		Rechange	
	Vol+		Vol +				
	Vol-		Vol -				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Menu		Menu				
	♪/Ton		Dual				
	Timer		AV				
	Zoom		Eject				
	TXT		Text				
	I>/Still		Pause				
	HDMI		Smart				
	PIP		3D				

