







































































Original		Rechange		Original		Rechange	
	Power		Power		FAV		Pre Ch
	Input		AV		Red		Red
	VF		Smart		Green		Green
	AR		Media		Yellow		Yellow
	SAT		Shift + TV/R		Blue		Blue
	TV / Radio		TV/R		Text		Text
	1		1		Mute		Mute
	2		2		Up		Up
	3		3		Right		Right
	4		4		Down		Down
	5		5		Left		Left
	6		6		OK		Ok
	7		7		Back		Back
	8		8		Exit		Exit
	9		9		V +		Vol +
	0		0		V -		Vol -
	Menu		Menu		P +		Ch +





Original	Recharge	Original	Recharge
	P -		Ch -
	APP		Shift + Media
	EPG		Guide
	Audio		Dual
	Sub		Subt
	Info		Info
	List		List

