



















Original	Recharge
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Return	 Back
 PR+	 Ch +
 PR-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 OK	 Ok
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green


Original	Recharge
 Yellow	 Yellow
 Info	 Info
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Stop	 Stop



















Original		Recharge		Original		Recharge	
	Rec		Rec				
	Pause		Pause				
	Play		Play				
	<<		<<				
	>>		>>				
	ZZZ/List		List				
	Guide		Guide				
	Zoom+		>>				
	Zoom-		<<				






Original	Recharge
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Return	 Back
 PR+	 Ch +
 PR-	 Ch -
 Menu	 Menu
 Exit	 Exit
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green


Original	Recharge
 Info	 Info
 Yellow	 Yellow
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Play	 Play


















Original		Recharge		Original	Recharge
	Stop		Stop		
	Pause		Pause		
	Rec		Rec		
	<<		<<		
	>>		>>		
	Zoom+		>>		
	Zoom-		<<		
	Zzz/List		List		
	Guide		Guide		






Original	Recharge
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 Return	 Back
 Exit	 Exit
 Menu	 Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green

Original	Recharge
 Info	 Info
 Yellow	 Yellow
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Rec	 Rec





Original	Recharge	Original	Recharge
Stop	Stop		
Pause	Pause		
Play	Play		
<<	<<		
>>	>>		
Zoom+	>>		
Zoom-	<<		
Zzz/List	List		
Guide	Guide		

