




Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Text	 Text
 Sub	 Subt
 TV	 Smart
 TV / Rad	 TV/R
 Audio	 Dual

Original	Rechange
 Page +	 Shift + Ch +
 Page -	 Shift + Ch -
 Up / Channel +	 Up
 Up / Channel +	 Ch +
 Down / Channel -	 Down
 Down / Channel -	 Ch -
 Right / Vol +	 Right
 Right / Vol +	 Vol +
 Left / Vol -	 Left
 Left / Vol -	 Vol -
 OK	 Ok
 Freeze	 Pause
 Menu	 Menu
 Browse	 Media
 EPG	 Guide
 Exit	 Exit
 Alt	 Back









































































Original	Recharge	Original	Recharge
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 i	 Info		





Original	Rechange
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Text	 Text
 Sub	 Subt
 TV	 Smart
 TV / Rad	 TV/R
 Audio	 Dual

Original	Rechange
 Page +	 Shift + Ch +
 Page -	 Shift + Ch -
 Up / Channel +	 Up
 Up / Channel +	 Ch +
 Down / Channel -	 Down
 Down / Channel -	 Ch -
 Right / Vol +	 Right
 Right / Vol +	 Vol +
 Left / Vol -	 Left
 Left / Vol -	 Vol -
 OK	 Ok
 Freeze	 Pause
 Menu	 Menu
 Browse	 Media
 EPG	 Guide
 Exit	 Exit
 Alt	 Back





Original	Recharge	Original	Recharge
	Red		
	Green		
	Yellow		
	Blue		
	Info		

