







































































Original		Recharge		Original		Recharge	
	Power		Power		Mute		Mute
	1		1		Guide/Top		Media
	2		2		Exit/Return		Exit
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Menu/DVD		Menu
	9		9		Tv/FAV/Radio/Set		TV/R
	0		0		Red		Red
	Source		AV		Green		Green
	ATV/DTV/Content Menu		Smart		Yellow		Yellow
	Vol+		Vol +		Blue		Blue
	Vol-		Vol -		[<>]		Format
	P+		Ch +		<[/]>		3D
	P-		Ch -		Subtitle		Subt









































































	Original	Rechange		Original	Rechange
	Text	 Text			
	II/II>/[▼]	 Pause			
	[i+]/[≡i]	 Info			
	O)I/II	 Dual			
	Stop	 Stop			
	Play/[≡o]	 Play			
	Eject	 Eject			
	I<</[≡?]	 I<<			
	<</[≡+]	 <<			
	>>/[≡◇]	 >>			
	>>I/[O]/[≡X]	 >>I			
	AD	 Shift + Subt			
	Audio	 Shift + Dual			









































































Original		Rechange		Original		Rechange	
	←[/]→		3D		Menu/DVD		Menu
	Power		Power		Tv/FAV/Radio/Set		TV/R
	1		1		Guide/Top		Guide
	2		2		[<>]		Format
	3		3		Text		Text
	4		4		Subtitle		Subt
	5		5		O) /II		Dual
	6		6		[i+]/[≡i]		Info
	7		7		OK		Ok
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	Source		AV		Left		Left
	Mute		Mute		/ >/[▼]		Pause
	Vol+		Vol +		Play/[≡o]		Play
	Vol-		Vol -		Stop		Stop
	Exit/Return		Exit		Eject		Eject





Original	Rechange	Original	Rechange
 Power	 Power	 P-	 Ch -
 ←[/]→	 3D	 Mute	 Mute
 1	 1	 Guide/Top	 Guide
 2	 2	 Exit/Return	 Exit
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 Ok
 8	 8	 Menu/DVD	 Menu
 9	 9	 Tv/FAV/Radio/Set	 TV/R
 0	 0	 Red	 Red
 Source	 AV	 Green	 Green
 ATV/DTV/Content Menu	 Smart	 Yellow	 Yellow
 Vol+	 Vol +	 Blue	 Blue
 Vol-	 Vol -	 Text	 Text
 P+	 Ch +	 [<>]	 Format



