












































Original	Recharge	Original	Recharge
	Power		Power
	Input		AV
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Lang		Dual
	TXT		Text
	Vol+		Vol +
	Vol-		Vol -

Original	Recharge	Original	Recharge
	Home		Smart
	P+		Ch +
	P-		Ch -
	[i+]		Info
	Guide		Guide
	Back		Back
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Prime Video		Shift + Smart





	Original	Recharge	Original	Recharge
	Netflix	Media		
	You Tube	Shift + Media		
	<<<	<<<		
	Pause	Pause		
	>>>	>>>		
	Rec	Rec		
	Play	Play		
	Stop	Stop		

