


























































Original	Rechange
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Lang	 Dual
 TXT	 Text
 P+	 Ch +
 P-	 Ch -
 Home	 Smart

Original	Rechange
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 [i+]	 Info
 Guide	 Guide
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Prime Video	 Shift + Smart





	Original	Rechange	Original	Rechange
	Netflix	Media		
	FPay	Shift + Media		
	Pause	Pause		
	>>	>>		
	<<	<<		
	Rec	Rec		
	Play	Play		
	Stop	Stop		

