







































































Original		Recharge		Original		Recharge	
	Power		Power		Exit/Back		Exit
	Mute		Mute		Up		Up
	1		1		Left		Left
	2		2		OK		Ok
	3		3		Right		Right
	4		4		Down		Down
	5		5		P+		Ch +
	6		6		P-		Ch -
	7		7		Vol+		Vol +
	8		8		Vol-		Vol -
	9		9		[<<>]		Format
	0		0		→ █ ←		TV/R
	Recall		Pre Ch		[i+] / [≡i]		Info
	Source		AV		Text / [≡] / [≡] []		Text
	Menu/DVD		Menu		▄▄▄▶ / ▾		Pause
	Guide		Guide		▶ / I/II		Play
	[■] [▄▄▄]		3D		▶ / I/II		Dual






















































































Original		Recharge		Original		Recharge	
	◀◀ / [≡○]		<<				
	◀◀ / [≡○]		Options				
	▶▶ / Subtitle		Subt				
	▶▶ / Subtitle		>>				
	▲		Smart				
	■ / [≡□]		Stop				
	⏏ / [≡⇅]		Eject				
	⏏ / [≡⇅]		I<<				
	▶▶ / [⊖][≡X]		>>I				
	▶▶ / [⊖][≡X]		Back				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				


















































































Original	Rechange	Original	Rechange
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	  / [v]	 Pause
 4	 4	  / I/II	 Play
 5	 5	  / I/II	 Dual
 6	 6	  / [≡●]	 <<<
 7	 7	  / [≡●]	 TV/R
 8	 8	  / Subtitle	 >>>
 9	 9	  / Subtitle	 Subt
 0	 0	  ▲	 Smart
 _ Menu/DVD	 Menu	  / [≡□]	 Stop
 - Exit/Back	 Exit	  / [≡⇅]	 Eject
 - Up	 Up	  / [≡⇅]	 I<<<
 Left	 Left	  / [⊙][≡X]	 >>>I
 OK	 Ok	  / [⊙][≡X]	 Back





Original	Recharge	Original	Recharge
 Power	 Power	 Mute	 Mute
 1	 1	 1	 1
 2	 2	 2	 2
 3	 3	 3	 3
 4	 4	 4	 4
 5	 5	 5	 5
 6	 6	 6	 6
 7	 7	 7	 7
 8	 8	 8	 8
 9	 9	 9	 9
 0	 0	 0	 0
Source	AV	Source	AV
P+	Ch +	P+	Ch +
P-	Ch -	P-	Ch -
Vol-	Vol -	Vol-	Vol -
Vol+	Vol +	Vol+	Vol +

Original	Recharge	Original	Recharge
 Pause	 Pause	 Play	 Play
 Play	 Dual	 Play	 Dual
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play
 Play	 Play	 Play	 Play

