




















Original		Recharge		Original		Recharge	
	Standby		Power		Pause		Pause
	TV Sys		TV/R		<<		<<
	Info		Info		>>		>>
	Zoom		Eject		I<<		I<<
	Select		Options		Stop		Stop
	Audio		Dual		>>I		>>I
	Subtitle		Subt		Vol+		Vol +
	Repeat		Text		Vol-		Vol -
	Home		Smart		Mute		Mute
	Menu		Menu				
	Return		Back				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	Play		Play				
	Enter		Ok				

